




# Ambient Display Cabinet

User Manual

ADS-60



P : 03 9783 6325

E : [sales@borrelli.com.au](mailto:sales@borrelli.com.au)

[www.borrelli.com.au](http://www.borrelli.com.au)

## Contents

- 01 Warnings and Safety
- 02 Installation and Cleaning
- 03 How to Use
- 04 Tips and Tricks
- 05 Specifications
- 06 Before Requesting Service
- 07 Warranty and Enquiries

## Warnings and Safety

*These precautions ensure safe, correct use of the display cabinet and minimise the risk of injury or damage.*

- Keep all ventilation openings clear.
- Do not use electrical appliances inside the cabinet.
- Do not store explosive or flammable substances inside the cabinet.
- Disconnect any lighting supply before cleaning or maintenance.
- This is an ambient (non-refrigerated) cabinet – do not rely on it to keep food cold or hot.
- Any electrical repair must be carried out by a qualified technician.



Maximum shelf load is 10 kg. Do not exceed the limit or place heavy items on the glass.


# Installation

## Before Use

- Remove all packaging.
- Wipe the shelves and interior with a soft, dry cloth before use.

## Placement

- Place on a firm, level counter.
- Keep out of direct sunlight to protect the contents.
- No refrigeration connection is required; if a display light is fitted, use a nearby socket.



## Cleaning



Always disconnect the power cord before cleaning.

### Exterior and Interior

- For dust, wipe inside and out with a dry cloth.
- For a deeper clean, use a mild detergent and a soft cloth.
- Clean the display cabinet regularly.
- Never use polishing powder, soap powder, benzine, oil or hot water – these damage the paint and plastic.



After cleaning, check the power cord for cracks or damage. If you find any, contact Borrelli.

Do not splash or wash the unit with water directly – this could cause a short circuit or shock.

## How to Use

This is an ambient display cabinet. It presents products at room temperature and does not refrigerate or heat.

### Loading the Cabinet

- Arrange stock evenly across the glass shelves.
- Do not exceed the shelf load limit or stack items above each shelf.
- Keep the door closed to keep dust off the contents.

### Shelves

- The glass shelves can be repositioned to suit taller items.
- Support the shelf when removing or refitting it.

### Lighting

If your cabinet is fitted with a display light, use the switch on the cabinet to turn it on and off.

## Tips and Tricks

Follow these tips to get the best presentation and lifespan from the cabinet.

### Placement

- Keep out of direct sunlight so the contents don't spoil or fade.
- Site it away from ovens, fryers and other heat sources.

### Shelves

- Adjust the glass shelves to suit what is on display.
- Distribute weight evenly and do not overload a single shelf.

### Cleaning

- Wipe the glass with a soft, dry cloth; use a mild glass cleaner for marks.
- Avoid abrasive powders that can scratch the glass.

Because it is not refrigerated, use this cabinet only for shelf-stable items such as bread, pastries or packaged snacks.

# Specifications

Figures are from the current product listings at [borrelli.com.au](http://borrelli.com.au).

| Specification  | ADS-60                     |
|----------------|----------------------------|
| Capacity       | 60 L                       |
| External W×D×H | 400 × 300 × 620            |
| Shelves        | 3                          |
| Door           | 1 hinged glass             |
| Type           | Ambient (non-refrigerated) |
| Weight         | 17 kg                      |

*Figures from [borrelli.com.au](http://borrelli.com.au) (SKU ADS-60). This is an ambient, non-refrigerated display cabinet.*

## Before Requesting Service

Please check the following if you encounter a problem. If it continues after these checks, contact Borrelli.

|                       |                                                                                                                                                                                                |
|-----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Door Not Sealing      | <ul style="list-style-type: none"><li>• Is the cabinet on a firm, level surface?</li><li>• Is anything blocking the door?</li><li>• Are the hinges secure?</li></ul>                           |
| Condensation on Glass | <ul style="list-style-type: none"><li>• Is the cabinet in a very humid area? Wipe the glass – this is normal in humid conditions.</li><li>• Is it sited near a heat source or steam?</li></ul> |
| Excessive Movement    | <ul style="list-style-type: none"><li>• Are all feet in firm contact with the counter?</li><li>• Is the cabinet overloaded on one side?</li></ul>                                              |

## Warranty and Enquiries

Warranty periods vary by product. For the period that applies to this model, see its product page at [borrelli.com.au](http://borrelli.com.au). For the warranty terms and how to make a claim, see our Terms & Conditions. Keep your proof of purchase, as it may be required.

### Enquiries

|         |                                                                  |
|---------|------------------------------------------------------------------|
| Phone   | 03 9783 6325                                                     |
| Email   | <a href="mailto:sales@borrelli.com.au">sales@borrelli.com.au</a> |
| Website | <a href="http://www.borrelli.com.au">www.borrelli.com.au</a>     |