




Upright Glass Door Freezer

User Manual

UF-580H • UF-1180H • UF-1780H



P : 03 9783 6325

E : sales@borrelli.com.au

www.borrelli.com.au

Contents

- 01 Warnings and Safety
- 02 Installation and Cleaning
- 03 How to Use
- 04 Tips and Tricks
- 05 Specifications
- 06 Before Requesting Service
- 07 Warranty and Enquiries

Warnings and Safety

These precautions ensure safe, correct use of the freezer and minimise the risk of injury or damage.

- Keep all ventilation vents clear while the unit is operating.
- Do not use mechanical devices to accelerate defrosting unless recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- The LED lights must be replaced by a qualified person – contact the customer helpline.
- Do not use electrical appliances inside the food storage compartment.



This product contains R290a flammable gas. Misuse could result in fire or serious injury.



If you find a gas leak, turn off the unit and open the door. Call your nearest repair agent or Borrelli.

- Do not damage, modify or excessively bend the power cord; if damaged, a qualified technician must replace it.
- Do not store explosive substances such as aerosol cans with flammable propellant in this appliance.
- Dispose of the unit only at an authorised waste centre; do not expose it to a flame.
- Disconnect the unit from power before cleaning, maintenance or replacing parts.
- All repairs, disassembly or modification must be performed by a qualified technician.
- Use a dedicated wall outlet; do not use flammable sprays or substances near the unit.
- The expected noise level of the unit is 55 dB.
- This unit is intended to store and display beverages for sale; do not use it for any other purpose.
- Do not insert anything (fingers, sticks, etc.) into the cold air suction outlet.
- Never place heavy objects or items containing water on top of the unit.
- After switching off, wait 5 minutes before restarting – restarting too soon can blow a fuse, trip the breaker or overload the compressor.
- Store bottles with a high alcohol content upright (vertically).



Maximum shelf load is 50 kg. Do not exceed the limit or throw items onto the shelves.


Installation

Before Use

- Remove all packaging and leave it open to ventilate.
- Clean the unit before use.
- Run the unit empty for an hour before loading.

Placement & Clearances

- Indoor use only; keep out of direct sunlight, rain and weather.
- Install on a flat, stable, level surface strong enough to support the unit when loaded.
- 20 mm gap on all sides; 100 mm at the rear for airflow.



Cleaning



Always disconnect the power cord before cleaning.

Exterior and Interior

- For dust, wipe inside and out with a dry cloth.
- For a deeper clean, use a mild detergent and a soft cloth.
- Clean the freezer regularly.
- Never use polishing powder, soap powder, benzine, oil or hot water – these damage the paint and plastic.



After cleaning, check the power cord for cracks or damage. If you find any, contact Borrelli.

Do not splash or wash the unit with water directly – this could cause a short circuit or shock.

How to Use

The freezer is controlled by the digital controller on the front of the unit.



Change Set Temperature

We recommend a freezing temperature between -18°C and -20°C .

1. Press and hold the Set button until you see the temperature set flashing (approx. 2 seconds) and then release this button. The temperature set will be flashing.
2. Adjust the temperature to your desired setting.
3. Press Set to save this temperature.
4. The controller should go back to showing the current temperature inside the unit.

Changing Variance Temperature

1. Press and hold the Set button until you see "P5" flashing. This should take about 7 seconds. Once flashing, release the button.
2. Press the Down arrow until you see "rd" on the display (1 press down), then press Set to enter into the setting. We want to check the flashing value on the controller.
3. Adjust the temperature to your desired setting. Once completed press the Set button to save the setting.
4. You will see the "rd" flashing again. Press and hold Set for approx. 5 seconds to return to the main screen.

Manual Defrost

1. Hold the snowflake button for about 3 seconds, then release.
2. A light with the snowflake symbol appears – defrosting has begun.
3. It switches off automatically when defrosting is complete.

Switches

The green switch powers the unit on; the red switch operates the interior light.

Tips and Tricks

Follow these tips to get the best performance, efficiency and lifespan from the freezer.

Transportation

- Do not tilt the unit beyond 45°.
- Allow it to stand for 12 hours before switching on, so the refrigerant can settle.
- Protect the power cord during transportation.

Drain Tray

- Defrosting is automatic; drain water collects in the tray and evaporates automatically.

Shelves

- Adjust the shelves to suit the items placed on them.
- Each shelf has a maximum load of 50 kg.

Condensation in a high-humidity environment is normal. Wipe it away with a damp cloth – this is not a defect.

Do not obstruct the fan by placing items in front of it. Keep the airflow clearances shown in Installation.

Specifications

Figures are from the current product listings at borrelli.com.au.

Specification	UF-580H	UF-1180H	UF-1780H
Doors	1	2	3
Capacity	459 L	1012 L	1560 L
External W×D×H	700 × 750 × 2050	1370 × 740 × 2107	2060 × 750 × 2050
Internal W×D×H	560 × 520 × 1300	—	1930 × 500 × 1300
Temperature range	-15 to -20 °C	-15 to -20 °C	-15 to -20 °C
Shelves	5	8	15 (5 per door)
Glass	Triple-layer heated	Triple-layer heated	Triple-layer heated
Interior lighting	LED	LED	LED
Mobility	Castors + brakes	Castors	6 castors + brakes
Power	15 A	15 A	15 A

Refrigerant R290a. UF-1180H external dimensions and shelf count cross-referenced from the supplier catalogue (Santa SD-1180F); its internal dimensions are not published.

Before Requesting Service

Please check the following if you encounter a problem. If it continues after these checks, contact Borrelli.

No Refrigeration	• Is the power supply interrupted? • Is the power cord securely connected? • Is a fuse blown or the breaker tripped?
Inadequate Refrigeration	• Is the temperature setting appropriate? • Is anything obstructing the air inlet or outlet? • Are stored items packed too tightly? • Is the door frequently opened or left ajar?
Excessive Noise	• Are all the feet in firm contact with the floor? • Is the back of the freezer touching the wall? • Are other objects resting on the freezer?

Warranty and Enquiries

Warranty periods vary by product. For the period that applies to this model, see its product page at borrelli.com.au. For the warranty terms and how to make a claim, see our Terms & Conditions. Keep your proof of purchase, as it may be required.

Enquiries

Phone	03 9783 6325
Email	sales@borrelli.com.au
Website	www.borrelli.com.au